


### Instructions

## Jatco/Nissan JF011E (RE0F10A)



#### 1. Disassembly

- a. Remove OE retainer pin and save for reuse.
- b. Remove OE lockup control valve train from bore and discard.

#### 2. Bore Reaming

Ream lockup control valve bore (for reaming instructions/reamer care, please visit www.sonnax.com). Sonnax reaming tool kit **F-113741-TL22** and **VB-FIX** are required for this operation.


#### **3. Installation & Assembly**

a. Be certain all debris has been removed from the valve bore and valve body.

- b. Install Sonnax control valve into reamed bore. Thin valve spool with flats must be outboard.
- c. Install Sonnax spring included with kit.
- d. Install Sonnax plunger valve and sleeve assembly with snout inside spring.
- e. Reinstall OE pin to retain sleeve.

#### 4. Final Testing

Vacuum testing at the port(s) indicated holds the recommended minimum 16 and 18 in-Hg.



# Oversized Lockup Control Valve Kit



- Control Valve
- Spring
- Plunger Valve
- Plunger Sleeve

NOTE: Also fits Mitsubishi F1CJA.



- Reamer
- Reamer Jig
- Guide Pin

**NOTE:** Sonnax "F-Tool" kits designed to service a specific bore require the VB-FIX, a self-aligning valve body reaming fixture. More information and instructions can be found online at www.sonnax.com.