Instructions


# **Clutch A Control Boost Valve Kit**

## Part No. 95740-21K

- Valve
- Sleeve

NOTE: Kit is NOT compatible with ZF6HP21/28/34 (Gen.2) units. To differentiate between Generation 1 and Generation 2 valve bodies, refer to ZF Identification Guide at www.sonnax.com.

### Ford 6R60, 6R75, 6R80; ZF6HP19, ZF6HP26, ZF6HP32



#### 1. Disassembly

- a. Remove and save OE retaining clip and end plug.
- b. Remove and discard OE boost valve and sleeve.

#### 2. Installation & Assembly

- a. Ensure all debris has been removed from valve bore and valve body.
- b. Install Sonnax boost valve and sleeve assembly.
- c. Reinstall OE end plug and secure with OE retaining clip.

#### 3. Final Testing

Vacuum testing at the port(s) indicated holds the recommended minimum 16 in-Hg.

