


HIGH PERFORMANCE TRANSMISSION PARTS

Instructions

## Heavy Duty 2-3 Shift Valve

Part No.

77754-41



## 1. Disassembly

- a. Remove and discard OE 2-3 shift valve.
- b. Retain all other OE bore components for reuse.

## 2. Installation & Assembly

- a. Drill through indicated casting wall with a 1/8" drill bit, using corner as a guide (**Figure 1**) to locate. This provides D3 oil to apply overrun clutch in all manual gears.
- b. Install Sonnax 2-3 shift valve.

