Instructions

Boost Valve & Sleeve Kit

Part No. 54200-06K

- Valve
- Sleeve

NOTE: Large boost ratio kit. Please see chart to verify.

Also Available


Boost Valve & Sleeve Kit

54200-14K Small/Medium Boost Ratio

Boost Valve & Sleeve Kit

54200-01K

Medium Boost Ratio



- 1. Remove OE boost valve and sleeve valve train.
- 2. Discard OE boost valve and sleeve, while retaining other parts for reuse.
- 3. Reassemble using Sonnax boost valve and sleeve as shown above.

| Sonnax Part No. | Boost Ratio | Sonnax I.D. Mark | OE/Euro I.D. Mark | Large Spool Diameter | Small Spool Diameter |
|-----------------|-----------------|---------------------|----------------------|-------------------------|-------------------------|
| 54200-14K | Small to Medium | 067 | 067 | .634" | .570" |
| 54200-01K | Medium | М | 448 | .662" | .630" |
| 54200-06K | Large | L | 264 | .697" | .649" |

©2012 Sonnax Industries, Inc. 54200-06K-IN 09-28-12