




GM 4L60-E, 4L65-E, 4L70-E, '04-Later



- 1. Place Loctite[®] #518 sealant on leading edge of stator support shaft before press operation.
- 2. Align oil holes and dowel holes exactly on the shaft and pump cover, then press shaft into the cover and fasten together.



Stator Support Shaft Assembly

Part No. 77918S-08K

Stator Support Shaft with Bushings Installed

NOTE: This assembly fits 298mm converters, reluctor style, '04–later.

Also Available

Universal Stator Support Kit 77918S-K

298mm or 245mm Converter, non-reluctor style

Stator Support Shaft Assemblies

77918S-1K 280mm or 300mm Converter, non-reluctor style

77918**S-**09K

280mm or 300mm Converter, reluctor style