




GM 4L60-E, 4L65-E, 4L70-E, '04-Later

To the store of th

- 1. Place Loctite® #518 sealant on leading edge of stator support shaft before press operation.
- 2. Align oil holes and dowel holes exactly on the shaft and pump cover, then press shaft into the cover and fasten together.



Large PWM Porting

Stator Support Shaft Assembly

Part No. 77918S-09K

Stator Support Shaft with Bushings Installed

NOTE: This assembly fits 280mm or 300mm converters, reluctor style, '04–later.

Also Available

Universal Stator Support Kit 77918S-K

245mm or 298mm Converter, non-reluctor style

Stator Support Shaft Assemblies

77918S-1K 280mm or 300mm Converter, non-reluctor style

77918S-08K

298mm Converter, reluctor style