Instructions

Ford **E40D**, 4R100

## **Sure Lock Spiral Snap Ring**

Part No.

36744-01

NOTE: Fits '89-Later.



## 1. Disassembly

- a. Using spring compressor, compress overdrive return spring.
- b. Remove and discard OE return spring retaining ring.

## 2. Installation & Assembly

a. Install one end of Sonnax Sure Lock ring into retaining ring groove.



WARNING: Do not use screw driver to install, force, or pry spiral snap ring into place.

- b. With ring end fully installed in groove, work the ring into the groove one wrap at a time (Figure 1).
- c. After ring is fully installed, make sure locking tabs are engaged with the cut-outs in retaining ring as shown. It may be necessary to bend locking tabs up to get a secure lock (Figure 2). Do not bend the cut-out ends.



WARNING: Be sure snap ring is installed correctly. Failure to install correctly may result in unit failure.



