TRANSMISSION PARTS

Instructions

Ford 4R100

TCC Control Plunger Valve Kit

Part No. 36424-08K


NOTE: Fits PWM units only.

NOTE: Use of the Sonnax kit does not convert hydraulics to On-Off for use with single piston conversion. The PWM control is a function of the computer and TCC/PWM solenoid.

Also Available

Oversized TCC Control Valve 36424-15K

NOTE: Fits PWM 4R100 units with F8 stamped pump castings only.



1. Disassembly

- a. Remove OE valve train.
- b. Discard OE TCC control plunger valve assembly.
- c. Retain OE TCC control valve, spring and clip for reuse.

2. Installation & Assembly

- a. Reinstall OE TCC control valve and spring.
- b. Install Sonnax TCC plunger valve and sleeve.
- c. Secure with OE clip.

NOTE: Vacuum test the TCC control valve. If leaking is found, replace with Sonnax oversized TCC control valve 36424-15K.

