TRANSMISSION PARTS

Instructions

Ford CD4E, Mazda LA4A-EL

Servo Return Spring

Part No. 73708



NOTE: Fits '94-'08 except applications with the shorter spring (**Figure 1**).



- 1. Replace OE servo return spring with Sonnax spring, referring to Ford CD4E technical manual for proper piston rod travel specifications and reassembly procedure.
- 2. Suggested servo travel is .110–.120"maximum. Travel can be identified by using a dial indicator and pushing on the cover with snap ring installed.
- 3. If the valve body is removed during rebuild, air test the servo apply and release circuits. No leakage should be evident. If leakage is present, the servo pin bores are worn or the piston seal is poor.

